

Tools Required:
10 mm socket
2 x 10 mm wrench
13 mm socket
Socket wrench

Included:
2 x gas struts
1 x Left hood bracket
1 x Right hood bracket
1 x Left lower bracket

1 x Right lower bracket
2 x Hood bracket clamps
4 x Hex bolts
4 x Hex nuts



Lower bracket



Hood Bracket



Right Side Complete

Step One

Right Side Lower Bracket Installation



Locate the two core support bolts as shown above.



Use 13 mm socket to remove. Install lower bracket using factory hardware.



Tighten lower bracket in place as shown. Please note direction of bracket.

Step Two

Right Side Hood Bracket Installation



Locate the two hood mount holes as shown above.



****Bolt with notch stays in place****

The upper bracket has one bolt that cannot be removed. Insert the inner hood clamp bracket into the slot as shown above.



Install the second bolt into the inner hood bracket and tighten with both with 10 mm socket.